


The TRIPOD

*One leg: camera falls down. Two legs: camera falls down.
Three legs: camera stands up. Four legs: one more leg than you need...*



Pan and Tilt Arm

Filament

Tilt lock lever

Tuning knob


Pedestal


Quick release button


Mounting Plate

Leg locks

CANON GL2







Battery Release Button

Stereo Microphone

MIC Terminal

Headphone Terminal

Open/Eject Switch

S-video In/Out Terminal

Focus Ring

Power Switch

White Balance (set) Button

White Balance Select Button

Tripod Socket

Zoom Controller

LCD Screen

Display/Data Code Button

Start/Stop Button

DV In/Out Terminal

AV(audio/video) Terminal